



MH-Z Series Infrared CO2 Sensor Module Communication Protocol

User's Manual

(Version 1.0)

Issue Date. 2020.11.30

Zhengzhou Winsen Electronics Technology Co., Ltd

Statement

This manual's copyright belongs to Zhengzhou Winsen Electronics Technology Co., LTD. Without the written permission, any part of this manual shall not be copied, translated, stored in database or retrieval system, also can't spread through electronic, copying, record ways.

Thanks for purchasing our product. In order to let customers use it better and reduce the faults caused by misuse, please read the manual carefully and operate it correctly in accordance with the instructions. If users disobey the terms or remove, disassemble, change the components inside of the sensor, we shall not be responsible for the loss.

The specific such as color, appearance, sizes &etc., please in kind prevail.

We are devoting ourselves to products development and technical innovation, so we reserve the right to improve the products without notice. Please confirm it is the valid version before using this manual. At the same time, users' comments on optimized using way are welcome.

Please keep the manual properly, in order to get help if you have questions during the usage in the future.

Zhengzhou Winsen Electronics Technology CO., LTD.

1. Profile for the communication protocol

- All the data in this communication protocol is hexadecimal.
- The data length is fixed 9 bits.
- Baud rate: 9600, data bit: 8, stop bit: 1, parity bit: none.

2. Command list and meaning.

Command and meaning	
0x86	To read CO2 concentration
0x9C(for wide range)	To read CO2 concentration
0x87	To calibrate zero point (ZERO)
0x79	To turn on/off self-calibrate function

3. Command list and meaning.

0x86- Read CO2 concentration (for 0-50000ppm range)								
Sending command								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Sensor No.	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x86	0x00	0x00	0x00	0x00	0x00	0x79
Return value								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Command	Concentration (High 8 Byte)	Concentration (Low 8 Byte)	-	-	-	-	Checksum
0xFF	0x86	0x01	0xF4	0x47	0x00	0x00	0x00	0xD1
CO2 concentration = HIGH * 256 + LOW								
Eg. 01 in hexadecimal is equals to 1 in decimal, F4 in hexadecimal is equals to 244 in decimal.								
CO2 concentration=01*256+244=500ppm								
0x9C- Read CO2 concentration (for 0-150000ppm range)								
Sending command								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Sensor No.	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x9C	0x00 by default	0x00	0x00	0x00	0x00	0x63
Return value								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Command	Concentration (High 8 Byte)	Concentration (Low 8 Byte)	-	-	-	-	Checksum
0xFF	0x9C	Data 1	Data 2	Data 3	Data 4	0x00	0x00	
CO2 concentration= Data 1 << 24 + Data 2 << 16 + Data 3 << 8 + Data 4								

0x87- Calibrate Zero point								
Sending command								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Sensor No.	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x87	0x00	0x00	0x00	0x00	0x00	0x78
No return value.								

0x79- On/Off Self-calibration for Zero Point								
Sending command								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x79	0xA0/0x00	0x00	0x00	0x00	0x00	Checksum
No return value.								
Note: when byte3 is 0xA0, the self-calibration function is turned on; when byte3 is 0x00, the self-calibration function is turned off. Self-calibration function is ON by default when the sensors leave the factory.								

Checksum calculation method								
Checksum = (Negative (Byte1+Byte2+Byte3+Byte4+Byte5+Byte6+Byte7))+1								
For example:								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x86	0x00	0x00	0x00	0x00	0x00	Checksum
Calculating Checksum:								
1、 Add Byte 1 to Byte 7: 0x01 + 0x86 + 0x00 + 0x00 + 0x00 + 0x00 + 0x00 = 0x87								
2、 Negative: 0xFF - 0x87 = 0x78								
3、 Then+1: 0x78 + 0x01 = 0x79								

C language								
<pre> char getChecksum(char *packet) { char i, checksum; for(i = 1; i < 8; i++) { checksum += packet[i]; } checksum = 0xff - checksum; </pre>								

Zhengzhou Winsen Electronics Technology Co., Ltd
Add: No.299, Jinsuo Road, National Hi-Tech Zone, Zhengzhou 450001 China
Tel: +86-371-67169097/67169670
Fax: +86-371-60932988
E-mail: sales@winsensor.com
Website: www.winsen-sensor.com