


## Pin Mapping of TFT Shield and Arduino DUE



F\_WP, F\_HOLD, F\_CS and SPI are pins used to control the flash. However, the flash is not soldered on the module by default. You could add one yourself.