Digital Counter & Timer

# **T21**

#### **INSTRUCTION MANUAL**

Thank you for purchasing HANYOUNG product. Please check whether the product is the exactly same as you ordered. Before using the product, please read this instruction manual carefully. Please keep this manual where you can view at any time

#### HANYOUNGNUX CO.,LTD

1381-3, Juan-Dong, Nam-Gu Incheon, Korea. TEL:(82-32)876-4697

FAX:(82-32)876-4696 http://www.hynux.net

#### INDONESIA FACTORY

HEAD OFFICE

#### PT. HANYOUNG ELECTRONIC INDONESIA

Jl. Jangari RT.003/002 Hegarmanah Sukaluyu Cianjur Jawa Barat Indonesia 43284 TEL: +62-2140001930



#### Safety information -

Alerts declared in the manual are classified to Danger, Warning and Caution by their criticality

⚠ DAN	GER	DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury
⚠ WAR	NING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury
⚠ CAU	TION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury



## Danger

Do not touch or contact the input/output terminals because they may cause electric shock.



- If there is a possibility of an accident caused by errors or malfunctions of this product, install external
  protection circuit to prevent the accident.
- This product does not contain an electric switch or fuse, so the user needs to install a separate electric switch or fuse externally. (Fuse rating: 250 V 0.5 A)
- To prevent defection or malfunction of this product, supply proper power voltage in accordance with the rating.
- After mounting the product onto a panel, please use a socket dedicated to the product when connecting
  with other units and do not turn on the power until completing wiring to prevent electric shock,
- Since this is not explosion—proof structure, please use in a place where corrosive gas (such as harmful gas, ammonia, etc.), combustible or explosive gas does not occur.
- Do not decompose, modify, revise or repair this product. This may cause malfunction, electric shock or fire.
- Attach or detach this product while the power is off. Otherwise, it may cause malfunction or electric shock.

## **Caution**

- · The contents of this manual may be changed without prior notice.
- Please check whether the product you purchased is the exactly same as you ordered.
- It you use the product with methods other than specified by the manufacturer, there may be bodily injuries or property damages.
- · Please check whether the product has no damage or abnormality during delivery.
- Do not use this product at any place with direct vibration or impact.
- Do not use this product at any place with liquid, oil, medical substances, dust, salt or iron contents, (Pollution level 1 or 2)
- Do not polish this product by substances such as alcohol or benzene.
- Do not use this product at any place with excessive induction trouble, static electricity or magnetic noise.
- Do not use this product at any place with possible thermal accumulation due to direct sunlight or heat radiation,
- Install this product at place under 2,000m in altitude.
- When the product gets wet, the inspection is essential because there is danger of an electric leakage or fire.
- If there is an excessive noise from power supply, it is recommended to use insulating transformer and noise filter. The noise filter must be attached to the panel grounded and wiring between the filter output side and power supply terminal should be as short as possible.
- If gauge cables are arranged too closely, the effect on noise may occur.
- · Do not connect anything to the unused terminals.
- · After checking polarity of terminal, connect wires to the right position.
- Install a switch or circuit breaker that allows the operator to immediately turn OFF the power, and label it to clearly indicate its function.
- For the continuous and safe use of this product, the periodic maintenance is recommended.
- Some parts of this product have limited life span, and others are changed by their usage.
- · The warranty period of this product including parts is one year if this product is properly used.
- When power is on, the preparation period of contact output is required. In case of using signals
  of external interlock circuit, use a delay Relay.

## Features

- Timing Relay (4a4b)
- Appearance 21.4 (W) X 28 (H) mm Timing relay
- · Plug in type (14 pins)
- · Customer sets time range and operation mode.
- Various time range (min / sec : 0.1 sec  $\sim$  60 min, hrs : 0.3 hrs  $\sim$  24 hrs)
- Multi operation mode (Power ON delay, Interval, Flicker OFF start, Flicker ON start)


#### Suffix code


Model	Code		е	Description			
T21 -	□-			Timing Relay			
	1			1 sec, 10 sec, 1 min, 10 min	Select by DIP switch		
Time	3			3 sec, 30 sec, 3 min, 30 min			
Range	6			6 sec, 60 sec, 6 min, 60 min			
	ЗН			3 hrs, 6 hrs, 12 hrs, 24 hrs			
Contact 4			4a4b				
Power supply voltage D24			A20	200 - 230 V a.c.			
			D24	24 V d.c.			
			A10	100 - 120 V a.c.			

#### Specification

-	0111011						
Model	AC	T21 - 1 / 3 / 6 / 3H - 4A20					
iviodei	DC	T21 - 1 / 3 / 6 / 3H - 4D24					
Power supply	AC	200 - 230 V a.c. 50/60 Hz					
voltage DC		24 V d.c.					
Power	AC	3.1 VA max (230 V a.c 60 Hz)					
consumption	DC	1.5 W max (24 V d.c)					
Reset time		100 ms max					
	1	0.1 sec $\sim$ 10 min					
Time Dence	3	0.3 sec $\sim$ 30 min					
Time Range	6	0.6 sec $\sim$ 60 min					
	3H	0.3 hrs $\sim$ 24 hrs					
Time tolerance		repetition tolerance : $\pm 1$ % max. (ratio of maximum scale) setting tolerance : $\pm 10$ % max. (ratio of maximum scale)					
	Output mode	Power on delay, Interval, Flicker OFF Start, Flicker ON Start					
Control output	Contact construction	4a4b					
	Capacity	250 V a.c 3A Resistive load					
Life expectancy		Mechanical: 10 million operations min, Electrical: 200,000 operations min					
Insulation resistance		100 MΩ min (at 500 V d.c, Between current-carrying terminals ar exposed noncurrent-carrying metal parts.)					
Dielectric strength		2000 V a.c 50/60 Hz 1 minute (Between current–carrying terminals and exposed noncurrent–carrying metal parts.)					
Noise im	nmunity	±2 kV (Between power terminal, pulse width ±1 µs, square wave noise by noise simulator)					
Vibration r	esistance	10 - 55 Hz (For 1 min), Double amplitude 0.75mm, X,Y,Z each direction for 1 hour					
Shock re	sistance	300 % X, Y, Z each direction for 3 times					
Ambient ter	mperature	$-10 \sim 50$ °C (Without condensation)					
Storage temperature		-25 ~ 65 °C (Without condensation)					
Ambient I	numidity	35 ~ 85 % RH					
Weig	ght	Approx. 42 g					

## Appearance






[Unit: mm]



## Part name and function -







	Name	Function				
1	Output ON indicator lamp (UP)	After setting time, light ON (Red) at the same time with output operation				
2	Power indicator lamp (PW)	Light ON after power ON (Green)				
3	Time setting knob	Set timer operation time, Setting time can be changed during operation of timer.				
4	Time unit	Time unit of setting time (min/sec, hrs).				
(5)	Time range setting (TIME RANGE)	Depend on suffix code, Select time range by DIP switches on the side				
6	Operating mode setting (OUT MODE)	Select output mode by DIP switches on the side				

## Connection diagram -

■ T21 - 1 / 3 / 6 / 3H - 4A20



■ T21 - 1/3/6/3H - 4D24



## Time Range -

Model	Time Range	Time setting Range	Setting			
	1 sec	0.1 ∼ 1 sec	Factory set			
9999 s	10 sec	1 ~ 10 sec				
3333 3	1 min	0.1 ∼ 1 min				
	10 min	1 ∼ 10 min				
	3 sec	0.3 ~ 3 sec	Factory set			
9999 s	30 sec	3 ~ 30 sec				
3333 3	3 min	$0.3\sim3$ min				
	30 min	3 ∼ 30 min				
	6 sec	$0.6\sim 6~{ m sec}$	Factory set			
9999 s	60 sec	6 ∼ 60 sec				
9999 \$	6 min	$0.6\sim 6$ min				
	60 min	$6\sim60$ min				
	3 hrs	$0.3\sim3~\mathrm{hrs}$	Factory set			
9999 s	6 hrs	$0.6\sim 6~\mathrm{hrs}$				
3333 8	12 hrs	1.2 $\sim$ 12 hrs				
	24 hrs	2.4 ~ 24 hrs				

<sup>\*</sup> Please turn off power to change Time range

## Operation

Output Mode	Operation Description	Timing Chart				Setting		
ON-Delay		Power	(3-(4)	Set time	Reset time	Set time	$\Box$	
_	When the power is ON, the output will be ON after setting time.	Time-limit NC	1-9, 2-10, 3-11, 4-12					
Power t		Time-limit NO	5-9, 6-0, 7-0, 8-2					
Output		Output indicator	UP LED					Factory set
* t : Set time		Power on indicator	PW LED					
Interval		Power	(3-(4)	Set time	Reset time	Set time	$\overline{\Box}$	
_	When the power is ON, the	Time-limit NC	1-9, 2-10, 3-11, 4-12				ㅂ	
Power t	output is ON and it will be OFF	Time-limit NO	5-9, 6-10, 7-11, 8-12				П	
Output	after setting time.	Output indicator	UP LED					
* t : Set time		Power on indicator	PW LED					
Flicker OFF-start		Set time   Set time   Set time   Set time   Set time				$\neg$		
· iididi di i dait	When the power is ON, the	Power	(3-14)	4 > 4			1	
Power — t , t , t , t , t	output is OFF and it repeatedly outputs OFF and ON with the setting time interval.		1-9, 2-10, 3-11, 4-12					
Output			5-9, 6-0, 7-0, 8-2				4	
Output —		Output indicator	UP LED				4	
* t : Set time		Power on indicator	PW LED				<u> </u>	
Flicker ON-start		Power	(3-(4)	Set time Set	et time Set time	Set time Set time	$\neg$	
	When the power is ON, the		1-9, 2-10, 3-11, 4-12				1	
Power t t t	output is ON and it repeatedly outputs ON and OFF with the setting time interval.		5-9, 6-10, 7-11, 8-12					
Output		Output indicator	UP LED				+	
* t : Set time		Power on indicator	PW LED					

<sup>\*</sup> Select output mode by 2 switches at the bottom of the four switches.